



CLASSIC

EAN-Code: 4006825642452

Als Sonderzubehör erhältlich



Power X-Boostcharger 6A
PXC-Ladegerät
Art.-Nr.: 4512064
EAN-Code: 4006825629019
Einhell Accessory



18V 2,0Ah Power X-Change
Akku
Art.-Nr.: 4511395
EAN-Code: 4006825610369
Einhell Accessory



18V 4,0Ah Power X-Change
Akku
Art.-Nr.: 4511396
EAN-Code: 4006825610376
Einhell Accessory



18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Art.-Nr.: 4512041
EAN-Code: 4006825613698
Einhell Accessory



18V 4,0Ah PXC Starter Kit TP
PXC-Starter-Kit
Art.-Nr.: 4512042
EAN-Code: 4006825613704
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Akku
Art.-Nr.: 4511437
EAN-Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
PXC-Ladegerät
Art.-Nr.: 4512069
EAN-Code: 4006825629729
Einhell Accessory



18V 3,0 Ah Power-X-Change
Akku
Art.-Nr.: 4511341
EAN-Code: 4006825590593
Einhell Accessory

Akku-Laufzeiten



Schrauben¹
(Stück)

Ein Akku Für alle Fälle

1.5 Ah	220
2.0 Ah	295
2.5 Ah	366
3.0 Ah	440
4.0 Ah	590
5.2 Ah	760
6.0 Ah	880

Testaufbau:

1) Schrauben - 6x60mm